

## **O & M INSTRUCTION**

### **PRODUCT GROUP 1907 EAZIBREETH**

#### **Safety**

This product is designed for domestic use, and this O&M is written from that usage point.

It is recommended that gloves, eye protection and nuisance dust masks are utilised when changing filters which have been subjected to natural air, especially for this product as the user may be sensitised to the dust within the unit.

The unit must be disconnected from the mains during filter changing.

#### **General**

The prefilter is located behind a cover tray at one end which is held on by 4 Allan headed screws. Once these are removed the prefilter pad is removed, discarded, and the new replacement fitted.

The HEPA filter is located behind a cover tray at one end which is held on by 4 Allan headed screws. Once these are removed the HEPA filter can be withdrawn from the unit and discarded. The new filter should be checked for obvious damage or abrasion to the filter pack, and if it passes inspection then slide it into the unit, relocate the cover tray and refit the 4 screws.

#### **Disposal of Air Filters Including Personal Protective Equipment**

- Filters and PPE have been damaged prior to use can be disposed of as normal domestic waste.
- Filters and PPE soiled with exterior air can be disposed of as normal domestic waste.
- Filters and PPE soiled by process air, bacterial, toxic and/or radioactive matter must be disposed of as Hazardous Waste in accordance with local regulations of the site and Environmental Health. Legislation prohibits removal of this waste from the site location.

For further information please contact Airclean Ltd